


## How to Import Start Lists for the Scoreboard from Hy-Tek software

There are two steps to transferring Start Lists from the computer running your Hy-Tek software to the computer controlling your scoreboard display.

1. Save the Start Lists to a USB flash drive or 3.5-inch floppy disk.
  - a. Insert the removable media into your Hy-Tek computer.
  - b. From the File menu in Hy-Tek, choose Export, then *Start Lists for Scoreboard*, then *Start Lists for CTS*. Select the appropriate destination for the removable media you have chosen. If you have questions, consult your Hy-Tek documentation.
  - c. Remove the media from your Hy-Tek computer.
  
2. Transfer the data from the USB flash drive or 3.5-inch floppy disk to the DisplayLink computer.
  - a. Insert the removable media into your DisplayLink computer.
  - b. Open the file transfer utility by double clicking the icon on the DisplayLink computer's desktop.
  - c. Select the drive you are copying from in the *Select Source Drive* menu.
  - d. Select the folder on the removable media from the *Select Source Folder* menu.
  - e. In the *Transfer the Files* section, click Copy \*.scb files.
  - f. When finished, click Quit.
  - g. Remove the media from your DisplayLink computer.

NOTE: If the icon for the utility is no longer on your computer's desktop, it can be found in C:\DisplayLink3\DLUSBtransfer.

Information is subject to change. Please see the CTS customer support website for latest details: [www.coloradotime.com/customersupport](http://www.coloradotime.com/customersupport)



Colorado Time Systems  
1551 E. 11<sup>th</sup> Street, Loveland, CO 80537  
Phone: 970-667-1000 x256 Toll free: 800-287-0653 ext. 256  
Fax: 970-667-1032 E-mail: [customerservice@coloradotime.com](mailto:customerservice@coloradotime.com)  
[www.coloradotime.com](http://www.coloradotime.com) Shop online: <http://secure.coloradotime.com>